



**DIGITECH**  
Audio

**User Manual**

**Infrared Wireless Stereo Headphones  
with Analogue and Digital Inputs**

**AA-2038**



Distributed by:  
TechBrands by Electus Distribution Pty Ltd  
320 Victoria Rd  
Rydalmere NSW 2116 Australia  
Ph: 1300 738 555  
Int'l: +61 2 8832 3200  
Fax: 1300 738 500  
[www.techbrands.com](http://www.techbrands.com)

## Specifications:

Operation Distance:	Up to 15 metres
On Headphone Controls:	- Volume - Channel Selection
Carrier Frequency (Infrared):	A Channel: 2.3MHz, 2.8MHz B Channel: 3.2MHz, 3.8MHz
Signal-to-noise ratio:	>55dB
Frequency Response:	30Hz to 20kHz
Headphone Weight:	153g (without batteries)
Headphone Power:	2 x AAA batteries (not included)
Transmitter Power:	12VDC
Dimensions (mm):	Base: 138(W) x 100(H) x 30(D) mm Headphones: 180(W) x 190(H) x 42(D) mm

## Flyout:



- 1 – Direction Indicators
- 2 – Battery Compartment
- 3 – Channel Selector
- 4 – Volume Control
- 5 – 3.5mm Stereo Input
- 6 – TOSLINK Input
- 7 – Power Input
- 8 – Power Switch/Channel Selector

## Instructions:

1. Plug in the transmitter to a power supply.
2. Plug in your audio to the 3.5mm stereo input and/or TOSLINK input of the transmitter.
3. Turn the transmitter on using the Power Switch/Channel Selector, set to channel A or B.
4. Position the transmitter so that the front is facing in the direction of the headphones.
5. Open the battery compartment of the headphones and insert batteries in the correct polarity.
6. Turn the headphones on using the channel selector, and set the channel to the same as the transmitter.
7. Adjust to the desired volume.

## NOTES:

- Never get the headphone or the transmitter wet.
- Never attempt to open, modify or repair any part of the headphone or the transmitter.
- Ensure to remove the batteries if the device is to be kept in storage.