



Single Channel Wireless UHF Microphone

With Compact Battery Operated Receiver

AM-4108



User Manual

Specifications:

Frequency:	525.5MHz
Frequency Response:	60Hz – 13kHz
Transmission range:	Up to 50m
Mic Power Supply:	1 x Rechargeable Battery Pack (3.7V 800mAh Li-Ion) 2 x AA batteries (not included)
Receiver Power Supply:	2 x AAA batteries
Dimensions:	
Microphone:	235(L) x 52(Dia.) mm
Receiver:	85(L) x 63(W) x 19(D) mm

Instructions:

1. Open the battery cover according to the markings and install 2 x AAA batteries in the correct polarity.
2. Turn on the receiver, the indicator light will turn on. When receiving a wireless signal, the indicator light will be brighter.
3. Insert the 3.5mm plug to a MIC input in an amplifier.
4. Unscrew the battery compartment of the microphone and insert 2 x AA batteries in the correct polarity, or use the rechargeable USB battery. Ensure that the rechargeable battery has been fully charged before using. Screw the battery compartment back in.
5. Turn the microphone ON by switching the power button on the front. Use the microphone as normal.

NOTE:

- Do not use the USB pack to recharge your rechargeable AA batteries.
- Do not attempt to open, repair or modify any part of the microphone or receiver.
- Do not get any part of the microphone or receiver wet.
- When the battery is low, the sound from the microphone will seem distorted. Please replace the batteries or charge the rechargeable battery.
- Remember to turn the microphone OFF when not in use.
- Remove the batteries from the microphone and receiver when the unit will not be used for a long period of time.

Distributed by:
TechBrands by Electus Distribution Pty. Ltd.
320 Victoria Rd, Rydalmere
NSW 2116 Australia
Ph: 1300 738 555
Int'l: +61 2 8832 3200
Fax: 1300 738 500
www.techbrands.com