



Error Codes

MB3611

Reverse polarity protect	Er1		Check charging clamp, connect the red clamp to positive (+) battery post, and black clamp to
Battery failed	Er2		Check the battery voltage is for 12V system
Failed in precharge stage.	Er3		Battery has problem. Replace with a new battery and try